

Installation Instruction

Model : 0102-0092

STEP 1. Remove existing body mount bolts from underside of cab.

STEP 2. Install **front mount bracket** and **rear mount bracket** with **M12-1.75 X 120MM HEX BOLT**. Leave bolts loose.

STEP 3. Fasten **step bar** to **mount brackets**. Check to be sure step bar is properly aligned with the truck. Tighten and torque all bolts.

STEP 4. Fasten **support strap** to **step bar**.

Item No.	Part Number	Part Description	QTY
1	0102-0092-01	STEP BAR - DRIVER,SIDE	1
2	0102-0092-02	STEP BAR - PASSENGER SIDE	1
3	0102-0092-03	MOUNT BRACKETS - FRONT	2
4	0102-0092-04	MOUNT BRACKETS - REAR	2
5	0102-0092-05	SUPPORT STRAP - FRONT	2
6	0102-0092-06	SUPPORT STRAP - REAR	2
7	0102-0092-11	M12-1.75 X 120MM HEX HEAD BOLT	4
8	0102-0092-12	1/2" x 1 3/8" FLAT WASHER	4
9	0102-0092-13	1/2" LOCK WASHER	4
10	0102-0092-14	3/8"-16 X 1" SELF THREADING BOLT	4
11	0102-0092-15	M14 X 2.5" HEX HEAD BOLT	4
12	0102-0092-16	M14 X 1" LOCK WASHER	4
13	0102-0092-17	M14 X 1 3/8" FLAT WASHER	4
14	0102-0092-18	M6 X 2" SELF THREADING SCREW	4
15	0102-0092-19	M6 X 1/2" LOCK WASHER	4
16	0102-0092-20	M6 X 1" FLAT WASHER	4





