

Installation Instruction

Model : 0108-0582

STEP 1. Verify all parts are present. Read instructions completely before beginning.

Note: Wrangler Sport models must have factory step pad removed for installation.

STEP 2. Attached step bars to brackets using M14 bolt set as shown. Leave loose.

STEP 3. Place threaded mount plates through underside of suspension so that the holes line up as shown. Attached brackets to mount plates using M12 bolt set as shown. Make sure step bar is properly aligned with vehicle body.

0108-0582			
Item No	Part Number	Part Description	QTY
1	0108-0582-01	STEP BAR - DRIVER SIDE	1
2	0108-0582-02	STEP BAR - PASSENGER SIDE	1
3	0108-0582-03	FRONT BRACKETS-DRIVR/PASSENGER SIDE	2
4	0108-0582-04	REAR BRACKET-DRIVER SDIE.	2
5	0108-0582-05	THREAD MOUNT PLATE	4
6	0108-0582-11	M14 HEX HEAD BOLT	4
7	0108-0582-12	M14 LOCK WASHER	4
8	0108-0582-13	M14 FLAT WASHER	4
9	0108-0582-14	M12 HEX HEAD BOLT	8
10	0108-0582-15	M12 LOCK WAHSER	8
11	0108-0582-16	M12 FLAT WASHER	8

