

0701-0020

2000-10 Chevy/GMC 1500LD/HD Crew Cab
2001-10 Chevy/GMC 2500/3500HD Crew Cab

Components List:

- 2 – Stainless steel oval step bars
- 2 – Front brackets
- 2 – Middle brackets
- 2 – Rear brackets
- 2 – Support braces
- 2 – Bolt plate

PARTS LIST:

- (1) 2 – Hex head bolts (10mm – 1.5 x 30 mm)
- (2) 2 – Flat washers (10 mm)
- (3) 6 – Flange lock nuts (10 mm – 1.5)
- (4) 12 – Hex head bolts (10 mm – 1.25x 30 mm)
- (5) 12 – Lock washers (10 mm)
- (6) 12 – Flat washers (10 mm)
- (7) 6 – Rubber gaskets

Installation Instruction:

1. Remove all contents from the received box and check stainless steel tube for any dent. Also verify all brackets and bolts against the parts list.
2. Read installation manual and installation drawing completely. Understand all brackets and bolts before installation.
3. Remove the body mount bolts from the front, mid and rear body mounts underneath cab of truck. (Keep the factory bolts and bushings)
4. Loosely bolt front, mid and rear mounting brackets to front, mid and rear body mounts using the factory bolts as shown Fig. A. (Make sure factory bushing is put on the same way it is taken off)



**Rear
Bracket**

**Center
Bracket**

**Front
Bracket**